

NOTES:

- 1. REPLACE ANY EXISTING 4" SIDE SEWER WITH 6" PVC AND TO EXTEND TO THE EDGE OF RIGHT-OF-WAY. REMOVE AND DISPOSE OF ANY EXISTING PIPE THAT IS NOT REUSED.
- 2. RELOCATE SIDE SEWER ONLY WHERE REQUIRED BY ROADWAY CUT.
- 3. CONNECT TO EXISTING SIDE SEWER AND MAIN STUB WITH ROMAC COUPLINGS OR EQUAL.



SEWER UTILITIES

TITLE

SIDE SEWER RELOCATION

NO. **S-21**

JANUARY 2015 NO SCALE